


IDS PRODUCT GUIDES

PFM5221DW




SOUTH AFRICA'S LEADING MANUFACTURER AND DISTRIBUTOR OF
ELECTRONIC SECURITY PRODUCTS

1.Quick installation guide




Set new Password




*******NOTE*******

Select and HOLD “Setting” tab **+ - 5 Seconds** till
Password screen comes up to enter into
configuration settings.



Select Network and Wired IP



Set Network settings / or Enable
DHCP, recommended to set as
STATIC, “DHCP=OFF”.

IDS PRODUCT GUIDES

PFM5221DW



SOUTH AFRICA'S LEADING MANUFACTURER AND DISTRIBUTOR OF
ELECTRONIC SECURITY PRODUCTS




Select WLAN, Swipe OFF, to switch ON WLAN, Select the Wireless you want to connect to and insert password



Select Wireless IP, set network settings or enable DHCP




For VTH server Setup



Sip server to be set to VTO's IP address, leave all settings as default, only Enable status to "ON"

For this example 172.26.7.42



For VTO Setup, Insert IP / user name and password of VTO , then switch Enable status to ON. You can also search for devices to add on the next tab.